



*Dimension "JJ" (tool block extension - distance between the tool block and the body) is normally "0". On powered slides with internal cushions (Option "HC"), dimension "JJ" is 1/8". To order Special Dimension "JJ", see Application Information for special options and ordering instructions.

**On 1/2, 3/4 and 1 1/8 bore powered slides, the cap-end port is located in the center of the cap.

***On 1/2, 3/4, and 1 1/8 bore powered slides with internal cushions (Option "HC"), dimension "Y" increases by 1". In addition, dimension "Y" will increase by 1" for 1/2, 3/4 and 1-1/8 bore powered slides series MPS.

DIMENSION REFERENCE	CYLINDER BORE				DIMENSION REFERENCE	CYLINDER BORE			
	1/2	3/4	1 1/8	1 1/2		1/2	3/4	1 1/8	1 1/2
A	2 1/4	2 25/64	3 17/64	3 11/16	S	7/8	1 5/32	1 19/32	1 3/4
B	3 1/4	3 7/8	5 1/2	6 35/64	T	1 1/8	1 5/16	1 13/16	2 1/8
C	1 1/8	1 1/4	1 45/64	2 13/64	U	11/16	25/32	1 1/8	1 1/2
D	5/8	7/8	1 1/4	1 5/8	V	1 9/16	1 5/8	2 13/32	2 3/4
E	3 1/8	3 13/16	5 3/8	6 29/64	W	1/16	1/16	1/10	1/10
F	1	1 1/8	1 1/2	2	X	1 5/16	1 5/16	1 9/16	1 9/16
G	2 1/8	2 5/8	3 5/8	4 1/4	Y	1/4	7/64	3/64	1 29/64
H	3/8	3/8	3/4	3/4	AA	1/4	1/4	3/8	1/2
J	1 1/8	1 5/16	1 13/16	2 1/8	BB	8-32	10-24	1/4-20	3/8-16
K	1 1/8	23/32	7/8	7/8	CC	3/8	1/2	5/8	13/16
L	3/4	15/16	1 1/2	1 15/16	DD	8-32	8-32	1/4-20	5/16-18
M	1 3/8	3 9/16	5	5 15/16	EE	3/8	3/8	1/2	5/8
N	11/32	3/8	7/16	15/32	FF	#8	#8	1/4	5/16
P	1/8-27	1/8-27	1/8-27	1/4-18	GG	1/4-20	1/4-20	3/8-16	1/2-13
Q	11/16	25/32	1 1/8	1 1/2 2 3/4	HH	3/8	1/2	3/4	1
R	1 9/16	1 5/8	2 13/32						